

# Computer Grafix – Printable Transparency Film Instructions for Use

## **Inkjet**

(non-adhesive films)

1. Handle film sheets on their edges to avoid fingerprints.
2. Ensure sheets are fully fanned.
3. For best results, you may need to adjust your printer driver to transparency film.
4. Be sure to print on the coated side (usually rougher texture).
5. In cassette-fed printers, follow machine instructions to print on the proper side of the film.
6. Please allow 5 minutes of drying time before stacking.

## **Inkjet**

(adhesive films)

1. Handle film sheets on their edges to avoid fingerprints.
2. Ensure sheets are fully fanned.
3. For best results, you may need to adjust your printer driver to transparency film.
4. Be sure to print on the coated side (usually rougher texture).
5. Place sheets in paper tray or feed through manual bypass.
6. Copy as normal.
7. When applying use a soft cloth to burnish the adhesive film down.

## **Laser/Copier**

(non-adhesive films)

1. This film is printable on both sides.
2. Handle film sheets on their edges to avoid fingerprints.
3. Ensure sheets are fully fanned.
4. Place sheets in paper tray or feed through manual bypass.
5. For best results, you may need to adjust your printer driver to transparency film.
6. Set number of copies to be produced and copy as normal.

